



Instructions on assembly and use

Please read all instructions carefully before use. Always obey safety precautions as mentioned in these instructions and on the warning label. Always use common sense safety practices, and monitor children's at all times. After reading, kindly store the instructions in a safe place for your future reference.

Item No: 350-047;(008-938;)

INSTALLATION

- The product should be assembled by an adult, referring to its assembly diagram or product images.
- USE 3 PCS "AA" Batteries, (Not Included)

FUNCTION BRIEF

- Made from 100% environment friendly materials, safe to use;
- indoor use .easy to setup;
- Parents and kids can play together for more intimate relationship.
- Inspires the children 's intellectual development.
- Improves the children 's ability to handle practical task.
- To improve children 's performing ability.
- Positive quality culture.



WARNINGS:

1. Adult assembly required!
2. don't swallow! Away from fire!
3. CHOKING HAZARD - Small parts!
Not for children under 3 years!
4. Please keep all the relevant information for future reference!
5. FOR AGES 3 years & ABOVE!
6. To be used under the direct supervision of an adult!

BATTERY WARNING

1. Batteries should always be replaced by an adult.
2. Batteries are to be inserted with the correct polarity. The supply terminals are not to be short-circuited.
3. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium or nickel metal hydride) batteries. Different types of batteries or new and used batteries are not to be mixed.

4. Exhausted batteries are to be removed from the toy.
5. Non-rechargeable batteries are not to be recharged.
6. Rechargeable batteries are to be removed from the toy before being charged. (if removable). Batteries are to be charged by adult, leaked or broken batteries are not to be charged.
7. Rechargeable batteries are only to be charged under adults' supervision.
8. Only batteries of the same or equivalent type as recommended are to be used.
9. Never put the batteries near fire or any source of heat, nor water or direct sunlight.
10. Do not dispose of battery in fire. Battery may explode or leak as a result.
11. Skin or clothing is to be washed immediately if you make contact with leaked liquid from the battery.
12. Remove batteries from the toy before prolonged storage.
13. For better preservation of rechargeable batteries, please regularly recharge it. And only a charger of the same or equivalent type as recommended are to be used.
14. Dispose of used batteries properly
15. Please retain this information for future reference.



0044-800-240-4004
enquiries@mhstar.co.uk