



INfbb023\_US\_CA

**350-122**



- \* Suitable for children of 3-6 years old.
- \* Maximum Weight Capacity of Chair: 40 Kg
- \* Maximum Weight Capacity of Table: 10 Kg

- \* Convient aux enfants de 3 à 6 ans.
- \* Poids maximum admissible de la chaise: 40 Kg
- \* Poids maximal admissible de la table: 10 Kg



**IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY**

# ASSEMBLY INSTRUCTION

**⚠ WARNING:**

1. CHOKING HAZARD—Small parts. Not for children under 3 years.
2. Only allowed for adults to install, keep children away.
3. To be used under the direct supervision of an adult.

**MAINTENANCE & CARE**

- A. Keep all instructions and parts relating to this product for future reference.
- B. Clean your toy with a clean damp cloth.

**BATTERY WARNING:**

1. Do not mix alkaline, standard or rechargeable batteries.
  2. Never mix old and new batteries.
  3. Batteries are to be inserted with the correct polarity.
  4. Remove the batteries when the unit is not in use for long periods.
  5. Always comply with local laws and regulations.
- 

**⚠ AVERTISSEMENT :**

1. RISQUE D'ÉTOUFFEMENT - Petites pièces. Déconseillé aux enfants de moins de 3 ans.

Installation par des adultes uniquement, tenir les enfants à l'écart.



2. À utiliser sous la surveillance directe d'un adulte.

**ENTRETIEN ET MAINTENANCE**


- A. Conservez toutes les instructions et les pièces relatives à ce produit pour pouvoir vous y référer ultérieurement.
- B. Nettoyez votre jouet avec un chiffon propre et humide.

**AVIS RELATIF AUX PILES :**

1. Ne pas mélanger les piles alcalines, standard ou rechargeables.
2. Ne mélangez jamais des piles anciennes avec de nouvelles piles.
3. Les piles doivent être insérées avec la bonne polarité.
4. Retirez les piles lorsque l'appareil n'est pas utilisé pendant une longue période.
5. Respectez toujours les lois et règlements locaux.



Open the battery cover with a screw-driver  
Uses 3 "AA" Size Batteries.(not included)



Open the battery cover with a screw-driver  
Uses 2 "AA" Size Batteries.(not included)

US



001-877-644-9366  
customerservice@aosom.com

CA



001-855-537-6088  
customerservice@aosom.ca

UK



0044-800-240-4004  
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530  
service@aosom.de

FR



0033-1-84166106  
contact@aosom.fr

ES



0034-931294512  
atencioncliente@aosom.es

IT



0039-0249471447  
clienti@aosom.it