







## Adult assembly required. Suitable for children from 3 to 6 years old. Maximum weight of children : 40 kg.

For family use only.

This product should always be used under the close supervision of an adult.

The product must be used on a stable and level surface. Do not install on hard ground, near steps, stairs, slopes, walls or glass. Make sure the reception areas are secure and free of any obstacles in a clear area of 2m around the product. When using the kit, children must wear gym shoes or non-slipshoes, non-slip socks or bare feet.

Before use, make sure that the equipment has been assembled and installed according to the instructions provided.

Report to the manufacturer any anomaly or deterioration observed.

Regularly check all plastic parts, their surface condition and their ft. Do not use the product again if a part is broken or has a non-reversible deformation.

The product can be cleaned with a non-abrasive sponge and soapy water.



001-877-644-9366 customerservice@aosom.com



0033-1-84166106 contact@aosom.fr



001-855-537-6088 customerservice@aosom.ca



0034-931294512 atencioncliente@aosom.es



0044-800-240-4004 enquiries@mhstar.co.uk



0039-0249471447 clienti@aosom.it



0049-(0)40-88307530 service@aosom.de

