




US C000000

**440-012**



- High-grade aluminum frame
- Reversible seat
- Equipped with shock absorbers
- Linked dual-brake
- Foldable and portable

Safety standard : ASTM F833-15 + 16 CFR1227

**ASSEMBLY INSTRUCTION**

# WARNING

---

Users and guardians, please read this specification carefully and keep it properly for your later reference it may affect children's safety if you don't follow this instructions. (if the specification pictures are not consistent with the product, please reference the product.)

1. When the product converted into pram body, this product is suitable for a child under six months old who cannot sit up unaided, roll over and cannot push itself on its hands and knees. Maximum weight of the child; 9kg, the pram body must be used with frame and not be used separately, and when used as pram body, don't forget to remove the seat belt. When the product converted into seat. the product is suitable for a baby 6 to 36 months old, the maximum weight is 15 kg.
2. Discard the plastic bags immediately, keep the plastic bags away from children
3. Ensure that all the locking devices are engaged before use.
4. Avoid serious injury falling or sliding out. Always use the restraint system.
5. Never leave your child unattended.
6. It will affect the stability of the stroller with any weight on handlebars.
7. You must enable the brake device as soon as the stroller stopped in order to avoid danger causing by sliding.
8. Over weight or error operations will affect functions of the stroller even damage its frame.
9. Accessories which are not approved by the manufacturers shall not be used.
10. Don't add up the additional mattress over thickness 8mm.
11. Don't use the cart in uneven occasions or someplace liable to turnover.
12. Make sure children's safety when adjusting the movable pass of the cart.
13. To avoid injury ensure that your child is kept away when unfolding and folding this product.
14. The shopping basket with maximum weight limit (3 kilos) no exceeding.
15. Don't carry two or more children.
16. Children are forbidden to climb from the guardrail or stand on the seat.
17. The parking device shall be engaged when placing and removing the children.
18. Keep away from the fire.
19. Do not let your child play with this product.
20. This product is not suitable for running or skating.
21. Can only use the manufacturer/retailer suggested or provided parts replacement parts.
22. Check that the pram body or seat unit or car seat attachment devices are correctly engaged before use.
23. Carrying handles shall be left out of the pram body during use.
24. Child may slip leg into openings and strangle. Never use in reclined carriage position(s) unless (manufacturer to insert product specific instructions).

# Parts name

---



# Assembly parts

---



Front wheel



Rear wheel



Children armrest



frame



Pram body/seat



Footcover

# Installation steps

---



1



2



3



4



5



6

As illustrated in picture 1 and 2, open the chassis ,when hear two click from both side ,it indicated that chassis has been opened completely.

Then you can get picture 3,next step , as illutrated in picture 4,insert rear wheel axle into chassis hole in arrow direction,when hear a click ,it indictaed that the rear wheel has been been installed.

As shown in figure 5, insert front wheel assembly into hole in chassis in arrow direction,when you hear click , it indicated that the front wheel assembly has been installed.After picture 5 step, then get picture 6.


In order to install pram body/seat,as picture 7 shown, insert pram body/seat adapter into hole chassis hole in direction as picture 7.



7

# User's Instruction

---



## Seat Reverse

As illustrated in picture 8, baby has his back towards his mother, when mother wants to face to face with baby, she just needs to press the button with thumb at the same time, pull out seat upwards as picture 9 in arrow direction, and rotate seat 180 degree, then insert seat downwards as picture 10.



## Seat Back Adjustment

As illustrated in picture 12, press button and rotate seat, then stop at the position you hope.

# User's Instruction

---



14


Wheel Released



15

As illustrated in picture 14,pressing the button, at the same time,pull the wheel assesmbly downwards,the you will release the front wheel assembly.

As illustrated in picture 15,pressing the button, and at the same time pull outwards the rear wheel assembly as arrow direction,the you will release the rear wheel assembly.




16

## Brake

As illustrated in picture 16,step pedal downwards as arrow B direction ,rear wheel asemmbly will be locked.

As illustrated in picture 16,step pedal downwards as arrow A direction ,rear wheel asemmbly will be released.

# User's Instruction



17




18



19

## Fold Stroller

As illustrated in picture 17, pressing the button with both handle on both side of the seat, and at the same time, fold the seat as picture 17,18,19.



20



21



22

## Fold Stroller

As illustrated in picture 20, first step, use forefinger press second lock, at the same time with other three fingers press button, last step, push downwards the handle as picture 21 arrow direction.



23



24



25



26



27

## Open


As illustrated picture 23,24, pull handle upwards, when hear two click, it indicated that the stroller has been opened, next step, open the seat of stroller as picture 25, then open the canopy totally as picture 26. ensure that both side joint are engaged firmly, push handle downwards and upwards, be sure that stroller will be not collapsed as picture 27.



# User's Instruction

## Restraint system removed/assembled

As shown in picture 28,30, put the seat belt 28 in the basket without cushion 30. As shown in picture 31, inserting the buckle in the hole in direction of the arrow. Then turnover 180, ensure the buckles are installed in place as picture 32,33. Conversely, remove the buckles from the holes, the basket without seat belt as picture 30.



1. Buckling up: As shown in picture 34, first ly, put A, B into C, D separately, resuling in picture 35, then put the part H, J into the notch of part M, seat belt is ok with clicking sound, pulling the belt forcely to ensure fasten it as the picture 36.
2. Seat belt opening.  
As shown in picture 36, pressing the button E, the seat automatically, then draw A, B. from C, D, respectively.

# User's Instruction

---



37



transition

38



39

## Seat-Prambody conversion

1. When the folding clasps of picture A.B.C are buttoned, please use the function seat.
2. When the folding clasps of picture A.B.C are taking off, please use the function of pram body.

## WARNING

- The function of pram body is suitable for a baby under six months old the maximum weight is 15kg.
- Must remove the seat belt when used as the pram body as shown in picture 29,30. must use the seat belt when used as children seat as shown in picture 32,33.
- Do not use the seat as pram body separately, it must be used with chassis together.
- Carrying handle shall be left out of the pram body during use.

## Maintenance

1. Check your baby stroller frequently, if there are screws loose or parts sagging.
2. When material and stitching burst, please replace and repair timely if needed.
3. Keep the stroller clean. Forbid putting sharp objects into the stroller so as to hurt kids.
4. Do not overuse or exert force to keep its service life.
5. Please wash textile with neutral detergent and warm water (10°C~40°C), avoiding to hurt cloth.
6. All rotations should be greased and lubricated with oil on time.
7. When dismantling, please follow instructions carefully to avoid unnecessary loss.

US



001-877-644-9366  
customerservice@aosom.com

CA



001-855-537-6088  
customerservice@aosom.ca

UK



0044-800-240-4004  
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530  
service@aosom.de

FR



0033-1-84166106  
contact@aosom.fr

ES



0034-931294512  
atencioncliente@aosom.es

IT



0039-0249471447  
clienti@aosom.it