

BABY WALKER

Use Instructions

432-001PK/BU/GN 201CE

Dear users,

Thank you for your purchasing. Please read the instructions carefully before use and keep them for future reference. It is concerning correct and safe assembly and use of the baby walking frame. The child may be hurt if you do not follow these instructions

WARNING — Never leave the child unattended.

WARNING — The child will be able to reach further and move rapidly when in the baby walking frame.

Use Instructions:

1. Assembled by adult
2. Prevent access to stairs, steps and uneven surfaces;
3. Guard all fires, heating and cooking appliances;
4. Remove hot liquids, electrical flexes and other potential hazards from reach;
5. Prevent collisions with glass in doors, windows and furniture;
6. Do not use the baby walking frame if any components are broken or missing;
7. This baby walking frame should be used only for less than 20 minutes.
8. This baby walking frame is intended to be used by children who can sit unaided, approximately from 6 to 12 months. It is not intended for children weighing more than 12 kg;
9. Do not use replacement parts other than those approved by the manufacturer or distributor;
10. Please check the child car over regularly, and keep it in safe places when not used.
11. Insert 2x AA batteries with the correct polarity.
12. Use non-rechargeable batteries . Different types or new and used batteries can not be used in mixture. Exhausted batteries should be removed.
13. The supply terminald are not to be short-circuited.
14. Please keep all the relevant information for future reference

Install Instruction

Step 1: Install Wheels

Insert wheels into the wheel axel holes under the base plate respectively, and press the wheel axles into the bottom in order to avoid dropping down. (Figure 1)




Figure 1

Step 2: Install Seat Cushion and Backrest

Insert the front and back plastic nails on the seat cushion into the corresponding holes and press them down (Figure 2 A), insert the back-cushion board into the corresponding hole in the panel, and tighten the nuts (Figure 2 B)




Figure 2

Step 3: Install Toy Music Tray

Open the cover of battery box at the back of the toy tray, install 2XAA batteries, and then the toy tray can be operated. Put the toy tray in the in the reserved place of top plan, aim at the position position to insert into it, and button the toy cover in order to avoid dropping down..




Figure 3

Notes: Different types or new and used batteries can not be used in mixture. When the batteries are not use, please take them out.The supply terminald are not to be short-circuited.

Step 4: Adjust the Height of Top Tray

There are use instruction on the riser, please detailedly read them.




Figure 4

BATTERY WARNING

1. Batteries should always be replaced by an adult.
2. Batteries are to be inserted with the correct polarity. The supply terminals are not to be short-circuited.
3. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium or nickel metal hydride) batteries. Different types of batteries or new and used batteries are not to be mixed.
4. Exhausted batteries are to be removed from the toy.
5. Non-rechargeable batteries are not to be recharged.
6. Rechargeable batteries are to be removed from the toy before being charged. (if removable). Batteries are to be charged by adult, leaked or broken batteries are not to be charged.
7. Rechargeable batteries are only to be charged under adults' supervision.
8. Only batteries of the same or equivalent type as recommended are to be used.
9. Never put the batteries near fire or any source of heat, nor water or direct sunlight.
10. Do not dispose of battery in fire. Battery may explode or leak as a result.
11. Skin or clothing is to be washed immediately if you make contact with leaked liquid from the battery.
12. Remove batteries from the toy before prolonged storage.
13. For better preservation of rechargeable batteries, please regularly recharge it. And only a charger of the same or equivalent type as recommended are to be used.
14. Dispose of used batteries properly
15. Please retain this information for future reference.

