



INfka013_UK

344-032



READ AND SAVE THIS INSTRUCTION FOR FUTURE USE

ASSEMBLY INSTRUCTION



WARNING:

- 1.ADULT ASSEMBLY REQUIRED.
- 2.KEEP SMALL PARTS OUT OF CHILDREN'S REACH,
CHOKING HAZARD SMALL PARTS.
- 3.NOT FOR CHILDREN UNDER 3 YEARS.
- 4.MAXIMUM LOADING WEIGHT:80KGS.



To assemble swing

1. Unpack the inflatable cushion and flatten it out. Then insert part of the cushion into the back of the swing, leaving the valve exposed.
2. Slowly inflate the cushion. When it is close to being fully inflated, completely insert into the bottom of the pod swing. Finish inflating when in place. Be careful not to over-inflate your cushion! If too full, you run the risk of popping it.



3. Cover the valve opening with your finger, then quickly insert the plug into the valve opening. Press the closed valve into the bladder so it is even with the surface.

Caution When Using the Bladder:

- Do not inflate this inflatable with an air compressor or any high-pressure hose at a filling station.
- Do not jerk on valve stems.
- This inflatable must be at room temperature before it is inflated. Otherwise it is at risk of temperature shock and can become defective.
- Do not drag this inflatable over sharp objects or surfaces.
- Avoid contact with hot or sharp objects.
- THIS IS NOT A LIFE-SAVING DEVICE.



001-877-644-9366
customerservice@aosom.com



001-855-537-6088
customerservice@aosom.ca



0044-800-240-4004
enquiries@mhstar.co.uk



0049-(0)40-88307530
service@aosom.de



0033-1-84166106
contact@aosom.fr



0034-931294512
atencioncliente@aosom.es



0039-0249471447
clienti@aosom.it