




USER INSTRUCTIONS

A20-025

Pay Attention

1. It is necessary to keep the mat away from fire and other heat objects. The foam in the mat is flammable.
2. Prevent sun exposure.
3. Do not use pumps to inflate the mat.
4. Keep away from sharp objects.

Inflate



1. At first spread the mat on a flat surface to moderate the inflation. Make sure that there are no sharp objects on the surface. Then unscrew the air-valve in an anti-clockwise direction to inflate the mat. (The air-valve is on the mat.)


2. Place the inflation mat on the flat floor, and after a few minutes, it will be filled. Then tighten the air-valve clockwise.

3. Pillow part blow with the mouth, pinch flat pillow inflatable mouth root with hand, Pinch charging port internal plastic sheet, make it open, Then blow air into the pillow.

4. At the end, drum bungs in place. (Inflatable mouth is on the pillow of the mat.)

❗ The mat can't inflation with external force, only automatically inflated. Filling time is about 10 minutes.

Deflate



☒ TRUE
SMOOTH



1. Open the inflatable mouth of the pillow, pinch flat pillow inflatable mouth root with hand, Pinch charging port internal plastic sheet, make it open, Slowly press the pillow to exhaust the air, then drum bungs in place.

2. Anti-clockwise open the air-valve to deflate.

3. Then fold the mat up under pressure to let the air out.

Close the valve when most of the air is out. After that roll the mat up while keeping pressure on it. When finished the deflate, tighten the air-valve clockwise.

4. Tighten the air-valve clockwise.

5. Roll the mat up while keeping pressure on it, tie up the elastic band.

☒ FALSE
TOO FULL

