

AIYAPLAY



INfja006_UK

370-226V00



CHILDREN TRICYCLE

* The maximum load is 25kg.

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

ASSEMBLY INSTRUCTION

WARNING

- 1. Read all instructions thoroughly before installing and using. Keep this manual for future reference.**
- 2. Adult assembly is required.**
- 3. Keep away from congested streets, roads, slopes, rivers and pools.**
- 4. Maximum load is 25kg. The specified age is 18-72 months. Do not exceed the maximum load.**
- 5. Before riding, ensure children understand how to properly use this tricycle.**
- 6. Children should wear protective clothing when riding. An adult should carefully check the trike before use, ensuring there are no damages.**
- 7. Adult supervision is always required.**
- 8. When unassembled, keep away from small children. There are small and sharp parts, which could be a potential choking hazard.**
- 9. Remove packaging and keep away from children to avoid suffocation.**
- 10. This product is suitable for one child at a time.**
- 11. A certain amount of skill is required when riding, preventing falls, collisions and injuries.**

Spare parts list



Trike framex1



Handlebar x2



Back leg fixed rod X 1



Subsidiary push rod X 1



Pedal X 2

Installing instruction



Figure 1

1. Pull up the head of the trike until you hear a 'click', which means the head is secure.




Figure 2

2. Insert the handlebar into the left and right hole of the head. Insert the leg fixed rod into the hole. This is for using as a balanced bike.

3. Assembling and disassembling the pedal
Insert the pedal into the hole of the wheel – you will hear a 'click', which means the pedal is secure.

Note: For the front wheel, the pedal can connect to two positions.

Outer position: Children can rest their feet on the pedals, so the trike can be pushed by a parent/guardian.

Inner position: The pedal will move the front wheel, so children can ride themselves.




Figure 3




Figure 4

4. Take out the fixed rod, then press the folding button – this will fold or unfold the back leg.



Figure 5

5. Press the button next to the wheel, then rotate the wheels outwards.



Figure 6

6. Before using, insert the rod into the hole on the leg. Children can ride the trike themselves.

Installing instruction



Figure 7



Figure 8



Figure 9

7. Take out the cover before inserting the push rod – a 'click' will signal the push rod is in place. This is for parents/guardians to push.

Using instruction

A. The position for placing the pedal.




B. To use as a balance bike.




1. When using as a balance bike, the pedal can be inserted in the back leg hole.

C. Push rod adjustment



2. Before adjusting the rod, push and hold the handle.

D



3. Before pulling out the push rod, press and hold the button.

