

INade036V02\_UK

A91-056




READ AND SAVE THIS INSTRUCTIONS FOR FUTURE USE


**ASSEMBLY & INSTRUCTION MANUAL** 

## Notices before exercise


- 1. Please read the manual carefully before exercise.
- 2. Please take warm-up exercise before using the equipment. Be aware of your physical ability and condition. Do not overuse.
- 3. Before exercise, please carefully examine the equipment make sure it is in good condition. If any defect, adjust and repair it before use. Ensure to wear proper outfit while using this equipment to avoid any possible dangerous circumstances.
- 4. The machine is intend for user over 12 years old. Users under 12 years old should exercise under adult's supervision.
- 5. Maximum load: 150KGS.

**Warning:** if there is a physical defects or movement disorders. Please consult the physician and trainer before exercise. Please read the manual carefully before use. We will not responsible for personal injury and damage to the equipment which is caused by improper use.







Socket Assembling: Take 4 sockets into the two foot bars  $\,$  (Make sure the socket is parallel to the floor. )



Foot Bar Connecting Pipe Assembling: Fix the foot bar with 4 M8X75mm screw. As follow,





Supporting bar Assembling: Fix the supporting bar with 4 pcs carriage M8\*45mm.




Main frame Assembly:

- 1. Fix the main frame bottom with 4pcs Carriage M8X45mm
- 2. Fix the main frame and supporting bar with Arc iron and hex(agonal) screw M8x75mm. As follow












3.Install the adjusting screw.




Supporting bar&Pull bar Assembly:

- 1.insert the supporting bar to the main frame with two plastic nuts.
- 2. Fix the pull bar to the two supporting bar with M8x75mm screw.



Rope Assembling: Take the rope in right position, as follow







customerservice@aosom.com

0033-1-84166106 contact@aosom.fr

001-855-537-6088 customerservice@aosom.ca

0044-800-240-4004 enquiries@mhstar.co.uk

0049-(0)40-88307530 service@aosom.de



0034-931294512 atencioncliente@aosom.es



0039-0249471447 clienti@aosom.it