


Dryer Maintenance:



1、 Loose screws in back cover first



2、 Then remove back cover



3、 Remove the filter



4、 Reload filter after cleaning



5、 Recover the back



6、 Finally, tighten the screws

PawHut INSTRUCTIONS



PET HOSED DRYER INSTRUCTION

Name: Pet Dryer

Output: 400W-2800W (Adjustable)

Wind speed: 25M/S-50M/S (Adjustable)

Temperature: 35°C-70°C (Adjustable)

Noise: ≤50dB

This dryer is super, powerful air speed and easy to use. The perfect low-noise design will bring you a better operating environment.

Patent No.: ZL201120147574.3

Patent No.: ZL201120147886.4

Patent No.: ZL201120147571.X

Patent No.: ZL201120147888.3

Operating instruction:

1、 Open package, take out machine, and check appearance and all accessories.

2、 As picture show, gently release the buckle, and join the front connector to the air outlet. Then adjust the buckle to fix it. After that, do as before, joining the other end of the air pipe with the blowing nozzle you wanted.

3、 Choose right voltage to avoid some damage.

4、 Make sure power is available, then turn on power switch. Adjust air speed. If needed, turn on heater with indicator light on. (Note: Don't turn on the heater's switch before the power's, or some damage maybe caused.)

5、 Clean filter film of the air inlet regularly, by disassembling screws of back cover, so as not to cause any blockage and damage.

6、 When machine does not work, check the power first. If still not work, don't fix the machine yourself, but give it to the professionals to repair it.

Friendly tips:

Power voltage should be 220V/110V. Do follow the instructions above, and rightly link the power. Do keep the machine away from the water, to prevent any inhalation of water, avoiding short-circuit of electrical components and any damage.



Installation detail:

- 1、 Gently release the ouch;
- 2、 Turn to loose;
- 3、 Rightly fasten chuck with the front cover;
- 4、 Turn to tighten;
- 5、 Repeat step1 with the other end;
- 6、 Select right nozzle;
- 7、 Fasten ouch with nozzle;

