

UK C000000

E30-001



**ROLLER SUPPORT STAND** 

**ASSEMBLY INSTRUCTION** 

### **SPECIFICATIONS**

Height:	27 - 43 ln.
Width:	17 ln.
Roller Width:	11 ln.
Weight Capacity:	132 lbs.
Weight <sup>.</sup>	8.8 lbs

Specifications are subject to change without notice

## **IMPORTANT SAFETY INFORMATION**

#### WARNING!

READ, UNDERSTAND AND FOLLOW ALL INSTRUCTIONS AND WARNINGS BEFORE OPERATING THIS TOOL. FAILURE TO DO SO MAY RESULT IN PERSONAL INJURY AND/OR PROPERTY DAMAGE AND WILL VOID WARRANTY.

- 1. Keep work area clean. Cluttered areas invite injuries.
- 2. Observe work area conditions. Ensure roller support stand is set up on firm, level ground in a stable manner.
- 3. Keep children away. Children must never be allowed in the work area. Do not let them handle machines, tools, or extension cords.
- 4. Be aware of over-balancing. When a large piece is cut from one end of a job, the remaining piece may be heavy enough to tip the stander. Always ensure the workpiece is well supported.
- 5. Use the right tool for the job. Do not modify this tool and do not use this tool for a purpose for which it was not intended.
- 6. Dress properly. Do not wear loose clothing or jewelry as they can be caught in moving parts. Protective, electrically non-conductive clothes and non-skid footwear are recommended when working. Wear restrictive hair covering to contain long hair.
- 7. Use eye and ear protection. Always wear ANSI approved impact safety goggles.
- 8. Work Safe. Keep proper footing and balance at all times. Never use support stand as step ladder, nor stand on support stand top. Never exceed recommended maximum weight capacity of support stand (132 lbs.). Always lower heavy loads onto stand gently, so that strain is taken up gradually.
- 9. Stay alert. Watch what you are doing, us common sense. Do not operate any tool when you are tired.
- 10. Check to make sure that all fixing screws and knobs are tight and all legs are locked into place before operating the stander.
- 11. Check damaged parts. Before further use of tool, it should be carefully checked to determine that it will operate properly and perform its intended function.
- 12. Do not operate any tool if under the influence of alcohol or drugs. Read warning labels on prescriptions to determine if your judgment or reflexes are impaired while taking drugs. If there is any doubt, do not operate any tool.
- 13. When not in use, tools should be stored in a dry locked-up place, out of the reach of children and do not allow persons unfamiliar with it.

# IMPORTANT SAFETY INFORMATION

WARNING - The use of any accessory or attachment other than one recommended in this instruction manual may present a risk of personal injury.

WARNING: The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator. Read and understand all of the instructions provided in the instruction manual as well as any other tool (s) used with the roller support stand.




### **ASSEMBLY INSTRUCTIONS**

Use hex key provided.

Step 1.

Remove the pins from the leg assembly (3) and insert the pins into the holes of the stand assembly (4) as shown in Fig. 1. Connect the leg assembly (3) and stand assembly (4) with the hex bolt as shown in Fig 2. Use the hex key to tighten the hex bolt, make sure the leg assembly is locked firmly as shown in Fig 3. Repeat this step with the other leg assembly (3).



# **ASSEMBLY INSTRUCTIONS CONT.**

### Step 3.

Put the roller assembly (1) on the stand assembly and connect them with two hex bolts and washers (5). Use the hex key to tighten the hex bolts as show in Fig 4.


#### Step 4.

NOTE: You can adjust the height of the stand with the adjustment handle by turning

counter-clockwise to loosen. While loose, raise the roller assembly to desired height and turn adjustment handle clockwise to tighten in place as shown in Fig 5.

NOTE: Set the roller assembly parallel with the leg assembly to support a longer work-piece more firmly.











001-877-644-9366

customerservice@aosom.com

0033-1-84166106 contact@aosom.fr



customerservice@aosom.ca



0044-800-240-4004 enquiries@mhstar.co.uk



0049-(0)40-88307530 service@aosom.de



0034-931294512 atencioncliente@aosom.es



0039-0249471447 clienti@aosom.it