


## **Assembly Instructions**



833-538WT

**Special Warnings:** 

- \* Please check that all parts are present before you start the assembly.
- \* For the protection of your furniture, place all parts on a clean and smooth surface to prevent any damage.
- \* For cleaning, wipe the surface with a damp (not wet) cloth or wipe dry with a clean lint free cotton cloth. Window cleaning liquid or a similar cleaning liquid can be used to clean the surface.
- \* This unit is heavy. Please use an assistant when lifting. Never drag or push the pieces across the floor as this will cause damage to the joints.
- \* Keep your furniture out of direct sunlight.

	HARDWA	HARDWARE LIST	
NO.		DESCRIPTION	QTY
A	(T	M6X34MM	#
В		ø15X12MM	44
Q		M6X30MM	16
D	(Canana)	M3. 5X14MM	40
E	Comm.	M4X38MM	8
F	Q	Handle	4
G	P	Neil pin	4
H	P	goupille Neil	20
I	Ø	M4X20MM	4
J		300111	2
K	Ş	M5*14MM	8
L		charnière	4
X	<i>Ц</i> 11"	Bracket/Strap	2

PARTS LIST			PARTS LIST		
NO.	DESCRIPTION	QTY	NO.	DESCRIPTION	QTY
1	800MM*340MM*15MM	1	10	288MM*295MM*3MM	2
2	921MM*285MM*15MM	1	11	336MM*140MM*15MM	1
3	921MM*285MM*15MM	1	12	336MM*140MM*15MM	1
4	680MM*335MM*15MM	1	13	740MM*336MM*15MM	2
5	675MM*310MM*15MM	2	14	680MM*335MM*15MM	1
6	680MM*310MM*15MM	1	15	320MM*145MM*15MM	1
7	300MM*90MM*15MM	2	16	1020MM*50MM*15MM	2
8	300MM*90MM*15MM	2	17	1020MM*50MM*15MM	2
9	277MM*90MM*15MM	2	18	778MM*331MM*3MM	3

